



Operator panel BTA15.1

Project Planning Manual

SYSTEM200

- Title** Operator panel BTA15.1
- Type of Documentation** Project Planning Manual
- Document Typecode** DOK-SUPPL*-BTA15.1****-PR01-EN-P
- Internal File Reference** • Document Number: 120-2100-B335-01/EN
- Purpose of Documentation** This documentation describes ...
- the hardwarefunctions of the BTA15
 - the technical datas
 - how connecting a BTA15

Record of Revisions

Description	Release Date	Notes
120-2100-B335-01/EN	07/00	First issue

- Copyright** © 2000 Rexroth Indramat GmbH
- Copying this document, giving it to others and the use or communication of the contents thereof without express authority, are forbidden. Offenders are liable for the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design (DIN 34-1).

- Validity** All rights are reserved with respect to the content of this documentation and the availability of the product.

- Published by** Rexroth Indramat GmbH
Bgm.-Dr.-Nebel-Str. 2 • D-97816 Lohr a. Main
Telephone 09352/40-0 • Tx 689421 • Fax 09352/40-4885
<http://www.rexroth.com/indramat>
Dept. ECH2 (CV)

- Note** This document has been printed on chlorine-free bleached paper.

Contents

1	System Presentation	1-1
1.1	Brief Description	1-1
1.2	Exceptional Features	1-1
2	Important directions for use	2-1
2.1	Appropriate use	2-1
	Introduction	2-1
	Areas of use and application.....	2-2
2.2	Inappropriate use	2-2
3	Safety Instructions for Electric Servo Drives and Controls	3-1
3.1	Introduction.....	3-1
3.2	Explanations.....	3-1
3.3	Hazards by inappropriate use	3-2
3.4	General Information	3-3
3.5	Protection against contact with electrical parts.....	3-4
3.6	Protection by protective low voltage (PELV) against electrical shock	3-6
3.7	Protection against dangerous movements.....	3-6
3.8	Protection against magnetic and electromagnetic fields during operations and mounting.....	3-8
3.9	Protection against contact with hot parts	3-9
3.10	Protection during handling and installation	3-9
3.11	Battery safety	3-10
3.12	Protection against pressurized Systems.....	3-10
4	Module Layout, Address Assignments	4-1
4.1	Base Module	4-1
	Instructions for installing additional switches	4-1
	Main board configuration	4-3
	Addressing	4-4
	Interface converter	4-5
4.2	Type NA Emergency Stop Module.....	4-6
	Addressing of the NA module	4-6
4.3	Type NB Emergency Stop Module.....	4-7
	Addressing of the NB module	4-8
4.4	Type VA Feed Module	4-9
	Addressing of the VA module	4-10
4.5	Type VB Feed Module	4-11
	Addressing of the VB module	4-11

5	Bus systems	5-1
5.1	Overview	5-1
5.2	INTERBUS-S	5-2
	Characteristics of the INTERBUS Module	5-2
	Status Displays	5-2
5.3	BT Bus.....	5-3
	Addressing	5-3
6	Technical Data	6-1
6.1	General Technical Data	6-1
6.2	Interface Converter	6-1
7	Connections	7-1
7.1	Location of the Terminal Connectors.....	7-1
7.2	24V Outputs X4 (potential free)	7-1
7.3	24V Inputs X5 (potential free)	7-1
7.4	INTERBUS-S Interface IN (X6).....	7-2
7.5	INTERBUS-S Interface OUT (X7).....	7-2
7.6	Interface RS232 IN (X8).....	7-2
7.7	Interface RS422 IN (X8A)	7-3
7.8	Interface RS422 OUT (X9).....	7-3
7.9	Terminal Connectors X1...X3.....	7-4
7.10	Terminal Connectors X4 and X5.....	7-5
7.11	E-Stop and Acknowledge Circuits.....	7-6
8	Dimensions	8-1
8.1	Enclosure Dimensions	8-1
8.2	Mounting Dimensions.....	8-2
9	Typical Applications	9-1
9.1	INTERBUS-S-Connection.....	9-1
9.2	BT Bus Connection	9-2
9.3	RS422 wiring with BTV06, MTS-R and BTC06.....	9-3
	Unit Arrangement.....	9-3
10	Ordering Information	10-1
10.1	Type code.....	10-1
10.2	Accessories.....	10-2
	Connectors and Standard Cables.....	10-2
11	List of Figures	11-1
12	Index	12-1
13	Kundenbetreuungsstellen - Sales & Service Facilities	13-1

1 System Presentation

1.1 Brief Description




Fig. 1-1: BTA15 Front view

The BTA15 was especially designed for use in conjunction with the BTV05/06. In this way, a suitable machine control panel consisting of three components is provided for the user. This panel can be equipped as needed and ordered according to project requirements.

1.2 Exceptional Features

Minimum wiring with high flexibility	Wiring is reduced to a minimum due to the slots for 22,5mm standard built-in components of the ZB2 series of Telemecanique. Subsequently mounted circuit elements are directly connected to the INTERBUS. The right auxiliary contact can be wired potential free by jumpers if needed.
30-pin socket	All contacts required for the hard-wired connection are available on three 10 pin socket (X1-X3). These are: <ul style="list-style-type: none"> • Emergency Stop, • acknowledge circuit and • a potential free contact of each standard built-in component, which can be connected from the bus to the socket via jumper.
Freely-configurable modules	Two emergency stop and three acknowledge circuits (for manual control units) are available on both module slots. Each module can be mounted left or right.
Integrated INTERBUS connection	The built-in INTERBUS adapter contains the entire, active electronics on a single printed circuit board. The BTA15 uses an I/O width of 3 words. Eight potential free 24V inputs and outputs are available for external connections (for example signal lamps, etc.).
Potential-free interface converter	The integrated interface converter serves the connection of the MTS-P's serial RS232 interface with the RS422 interfaces of the small human machine interface BTV05 or the manual control unit BTC06 without the need to equip the MTS-P with in additional interface board.

2 Important directions for use

2.1 Appropriate use

Introduction

Rexroth Indramat products represent state-of-the-art developments and manufacturing. They are tested prior to delivery to ensure operating safety and reliability.

The products may only be used in the manner that is defined as appropriate. If they are used in an inappropriate manner, then situations can develop that may lead to property damage or injury to personnel.

Note: Rexroth Indramat, as manufacturer, is not liable for any damages resulting from inappropriate use. In such cases, the guarantee and the right to payment of damages resulting from inappropriate use are forfeited. The user alone carries all responsibility of the risks.

Before using Rexroth Indramat products, make sure that all the prerequisites for appropriate use of the products are satisfied:

- Personnel that in any way, shape or form uses our products must first read and understand the relevant safety instructions and be familiar with appropriate use.
- If the product takes the form of hardware, then they must remain in their original state, in other words, no structural changes are permitted. It is not permitted to decompile software products or alter source codes.
- Do not mount damaged or faulty products or use them in operation.
- Make sure that the products have been installed in the manner described in the relevant documentation.

Areas of use and application

The BTA15.1 is a suitable machine control panel provided for the user. This panel can be equipped as needed and ordered according to project requirements. The BTA15.1 terminal made by Rexroth Indramat is designed for use in the following cases:

- To operate control units of a machine.
- In especially realisations to connect a manual control unit BTC06.

Note: The BTA15.1 may only be used with the accessories and parts specified in this document. If a component has not been specifically named, then it may not be either mounted or connected. The same applies to cables and lines.

Operation is only permitted in the specified configurations and combinations of components using the software and firmware as specified in the relevant function descriptions.

Available for an application-specific use of the terminals are unit types with differing drive power and different interfaces.

Typical areas of application of a BTA15.1 are:

- lathes
- milling machines and
- machining centers.

The BTA15.1 may only be operated under the assembly, installation and ambient conditions as described here (temperature, system of protection, humidity, EMC requirements, etc.) and in the position specified.

2.2 Inappropriate use

Using the motors outside of the above-referenced areas of application or under operating conditions other than described in the document and the technical data specified is defined as "inappropriate use".

The terminals may not be used if

- they are subject to operating conditions that do not meet the above specified ambient conditions. This includes, for example, operation under water, in the case of extreme temperature fluctuations or extreme maximum temperatures or if
- Rexroth Indramat has not specifically released them for that intended purpose. Please note the specifications outlined in the general Safety Instructions!

3 Safety Instructions for Electric Servo Drives and Controls

3.1 Introduction

Read these instructions before the equipment is used and eliminate the risk of personal injury or property damage. Follow these safety instructions at all times.

Do not attempt to install, use or service this equipment without first reading all documentation provided with the product. Read and understand these safety instructions and all user documentation of the equipment prior to working with the equipment at any time. If you do not have the user documentation for your equipment contact your local Rexroth Indramat representative to send this documentation immediately to the person or persons responsible for the safe operation of this equipment.

If the product is resold, rented or transferred or passed on to others, then these safety instructions must be delivered with the product.



WARNING

Inappropriate use of this equipment, failure to follow the safety instructions in this document or tampering with the product, including disabling of safety devices, may result in product damage, personal injury, severe electrical shock or death!

3.2 Explanations

The safety warnings in this documentation describe individual degrees of hazard seriousness in compliance with ANSI:

Warning symbol with signal word	Degree of hazard seriousness
 DANGER	The degree of hazard seriousness describes the consequences resulting from non-compliance with the safety guidelines. Bodily harm or product damage will occur.
 WARNING	Death or severe bodily harm may occur.
 CAUTION	Death or severe bodily harm may occur.

Fig. 3-1: Classes of danger with ANSI

3.3 Hazards by inappropriate use



DANGER

**High voltage and high discharge current!
Danger to life, risk of severe electrical shock
and risk of injury!**



DANGER

**Dangerous movements! Danger to life and risk
of injury or equipment damage by unintentional
motor movements!**



WARNING

**High electrical voltage due to wrong
connections! Danger to life, severe electrical
shock and severe bodily injury!**



WARNING

**Health hazard for persons with heart
pacemakers, metal implants and hearing aids in
proximity to electrical equipment!**



CAUTION

**Surface of machine housing could be extremely
hot! Danger of injury! Danger of burns!**



CAUTION

**Risk of injury due to inappropriate handling!
Bodily injury caused by crushing, shearing,
cutting and mechanical shock or improper
handling of pressurized systems!**



CAUTION

**Risk of injury due to inappropriate handling of
batteries!**

3.4 General Information

- Rexroth Indramat GmbH is not liable for damages resulting from failure to observe the warnings given in these documentation.
- Order operating, maintenance and safety instructions in your language before starting up the machine. If you find that due to a translation error you can not completely understand the documentation for your product, please ask your supplier to clarify.
- Proper and correct transport, storage, assembly and installation as well as care in operation and maintenance are prerequisites for optimal and safe operation of this equipment.
- Trained and qualified personnel in electrical equipment:
Only trained and qualified personnel may work on this equipment or within its proximity. Personnel are qualified if they have sufficient knowledge of the assembly, installation and operation of the product as well as an understanding of all warnings and precautionary measures noted in these instructions.
Furthermore, they should be trained, instructed and qualified to switch electrical circuits and equipment on and off, to ground them and to mark them according to the requirements of safe work practices and common sense. They must have adequate safety equipment and be trained in first aid.
- Only use spare parts and accessories approved by the manufacturer.
- Follow all safety regulations and requirements for the specific application as practiced in the country of use.
- The equipment is designed for installation on commercial machinery.

European countries: see directive 89/392/EEC (machine guideline).

- The ambient conditions given in the product documentation must be observed.
- Use only safety features that are clearly and explicitly approved in the Project Planning manual.
For example, the following areas of use are not allowed: Construction cranes, Elevators used for people or freight, Devices and vehicles to transport people, Medical applications, Refinery plants, the transport of hazardous goods, Radioactive or nuclear applications, Applications sensitive to high frequency, mining, food processing, Control of protection equipment (also in a machine).
- Start-up is only permitted once it is sure that the machine, in which the product is installed, complies with the requirements of national safety regulations and safety specifications of the application.
- Operation is only permitted if the national EMC regulations for the application are met.
The instructions for installation in accordance with EMC requirements can be found in the INDRAMAT document "EMC in Drive and Control Systems".
The machine builder is responsible for compliance with the limiting values as prescribed in the national regulations and specific EMC regulations for the application.

European countries: see Directive 89/336/EEC (EMC Guideline).

U.S.A.: See National Electrical Codes (NEC), National Electrical Manufacturers Association (NEMA), and local building codes. The user of this equipment must consult the above noted items at all times.

- Technical data, connections and operational conditions are specified in the product documentation and must be followed at all times.

3.5 Protection against contact with electrical parts

Note: This section refers to equipment with voltages above 50 Volts.

Making contact with parts conducting voltages above 50 Volts could be dangerous to personnel and cause an electrical shock. When operating electrical equipment, it is unavoidable that some parts of the unit conduct dangerous voltages.



DANGER

High electrical voltage! Danger to life, severe electrical shock and severe bodily injury!

- ⇒ Only those trained and qualified to work with or on electrical equipment are permitted to operate, maintain or repair this equipment.
- ⇒ Follow general construction and safety regulations when working on electrical installations.
- ⇒ Before switching on power the ground wire must be permanently connected to all electrical units according to the connection diagram.
- ⇒ Do not operate electrical equipment at any time if the ground wire is not permanently connected, even for brief measurements or tests.
- ⇒ Before working with electrical parts with voltage potentials higher than 50 V, the equipment must be disconnected from the mains voltage or power supply.
- ⇒ The following should be observed with electrical drives, power supplies, and filter components:
Wait five (5) minutes after switching off power to allow capacitors to discharge before beginning work. Measure the voltage on the capacitors before beginning work to make sure that the equipment is safe to touch.
- ⇒ Never touch the electrical connection points of a component while power is turned on.
- ⇒ Install the covers and guards provided with the equipment properly before switching the equipment on. Prevent contact with live parts at any time.
- ⇒ A residual-current-operated protective device (r.c.d.) must not be used on an electric drive! Indirect contact must be prevented by other means, for example, by an overcurrent protective device.
- ⇒ Equipment that is built into machines must be secured against direct contact. Use appropriate housings, for example a control cabinet.

European countries: according to EN 50178/1998, section 5.3.2.3.

U.S.A: See National Electrical Codes (NEC), National Electrical Manufacturers Association (NEMA) and local building codes. The user of this equipment must observe the above noted instructions at all times.

To be observed with electrical drives, power supplies, and filter components:



DANGER

**High electrical voltage! High leakage current!
Danger to life, danger of injury and bodily harm
from electrical shock!**

- ⇒ Before switching on power for electrical units, all housings and motors must be permanently grounded according to the connection diagram. This applies even for brief tests.
- ⇒ Leakage current exceeds 3.5 mA. Therefore the electrical equipment and units must always be firmly connected to the supply network.
- ⇒ Use a copper conductor with at least 10 mm² cross section over its entire course for this protective connection!
- ⇒ Prior to startups, even for brief tests, always connect the protective conductor or connect with ground wire. High voltage levels can occur on the housing that could lead to severe electrical shock and personal injury.

European countries: EN 50178/1998, section 5.3.2.1.

USA: See National Electrical Codes (NEC), National Electrical Manufacturers Association (NEMA), and local building codes. The user of this equipment must maintain the above noted instructions at all times.

3.6 Protection by protective low voltage (PELV) against electrical shock

All connections and terminals with voltages between 5 and 50 Volts on INDRAMAT products are protective low voltages designed in accordance with the following standards on contact safety:

- International: IEC 364-4-411.1.5
- EU countries: see EN 50178/1998, section 5.2.8.1.



WARNING

High electrical voltage due to wrong connections! Danger to life, severe electrical shock and severe bodily injury!

- ⇒ Only equipment, electrical components and cables of the protective low voltage type (PELV = Protective Extra Low Voltage) may be connected to all terminals and clamps with 0 to 50 Volts.
- ⇒ Only safely isolated voltages and electrical circuits may be connected. Safe isolation is achieved, for example, with an isolating transformer, an opto-electronic coupler or when battery-operated.

3.7 Protection against dangerous movements

Dangerous movements can be caused by faulty control or the connected motors. These causes are be various such as:

- unclean or wrong wiring of cable connections
- inappropriate or wrong operation of equipment
- malfunction of sensors, encoders and monitoring circuits
- defective components
- software errors

Dangerous movements can occur immediately after equipment is switched on or even after an unspecified time of trouble-free operation.

The monitors in the drive components make faulty operation almost impossible. Regarding personnel safety, especially the danger of bodily harm and property damage, this alone should not be relied upon to ensure complete safety. Until the built-in monitors become active and effective, it must be assumed in any case that some faulty drive movements will occur. The extent of these faulty drive movements depends upon the type of control and the state of operation.

**Dangerous movements! Danger to life and risk of injury or equipment damage!**

⇒ Personnel protection must be secured for the above listed reason by means of superordinate monitors or measures.

These are instituted in accordance with the specific situation of the facility and a danger and fault analysis conducted by the manufacturer of the facility. All the safety regulations that apply to this facility are included therein. By switching off, circumventing or if safety devices have simply not been activated, then random machine movements or other types of faults can occur.

Avoiding accidents, injury or property damage:

⇒ Keep free and clear of the machine's range of motion and moving parts. Prevent people from accidentally entering the machine's range of movement:

- use protective fences
- use protective railings
- install protective coverings
- install light curtains or light barriers

⇒ Fences must be strong enough to withstand maximum possible momentum.

⇒ Mount the emergency stop switch (E-stop) in the immediate reach of the operator. Verify that the emergency stop works before startup. Don't operate the machine if the emergency stop is not working.

⇒ Isolate the drive power connection by means of an emergency stop circuit or use a start-inhibit system to prevent unintentional start-up.

⇒ Make sure that the drives are brought to standstill before accessing or entering the danger zone.

⇒ Secure vertical axes against falling or slipping after switching off the motor power by, for example:

- Mechanically securing the vertical axes
- Adding an external brake / clamping mechanism
- Balancing and thus compensating for the vertical axes mass and the gravitational force

The standard equipment motor brake or an external brake controlled directly by the servo drive are not sufficient to guarantee the safety of personnel!

- ⇒ Disconnect electrical power to the equipment using a master switch and secure the switch against reconnection for:
 - maintenance and repair work
 - cleaning of equipment
 - long periods of discontinued equipment use
 - ⇒ Avoid operating high-frequency, remote control and radio equipment near electronics circuits and supply leads. If use of such equipment cannot be avoided, verify the system and the plant for possible malfunctions at all possible positions of normal use before the first start-up. If necessary, perform a special electromagnetic compatibility (EMC) test on the plant.
-

3.8 Protection against magnetic and electromagnetic fields during operations and mounting

Magnetic and electromagnetic fields generated by current-carrying conductors and permanent magnets in motors represent a serious health hazard to persons with heart pacemakers, metal implants and hearing aids.



WARNING

Health hazard for persons with heart pacemakers, metal implants and hearing aids in proximity to electrical equipment!

- ⇒ Persons with pacemakers, metal implants and hearing aids are not permitted to enter following areas:
 - Areas in which electrical equipment and parts are mounted, being operated or started up.
 - Areas in which parts of motors with permanent magnets are being stored, operated, repaired or mounted.
 - ⇒ If it is necessary for a person with a pacemaker to enter such an area, then a physician must be consulted prior to doing so. Pacemaker, that are already implanted or will be implanted in the future, have a considerable deviation in their resistance to interference. Due to the unpredictable behavior there are no rules with general validity.
 - ⇒ Persons with hearing aids, metal implants or metal pieces must consult a doctor before they enter the areas described above. Otherwise health hazards will occur.
-

3.9 Protection against contact with hot parts



Housing surfaces could be extremely hot!
Danger of injury! Danger of burns!

- ⇒ Do not touch surfaces near the source of heat! Danger of burns!
- ⇒ Wait ten (10) minutes before you access any hot unit. Allow the unit to cool down.
- ⇒ Do not touch hot parts of the equipment, such as housings, heatsinks or resistors. Danger of burns!

3.10 Protection during handling and installation

Under certain conditions inappropriate handling and installation of parts and components may cause injuries.



Risk of injury through incorrect handling!
Bodily harm caused by crushing, shearing, cutting and mechanical shock!

- ⇒ Observe general instructions and safety regulations during handling installation.
- ⇒ Use only appropriate lifting or moving equipment.
- ⇒ Take precautions to avoid pinching and crushing.
- ⇒ Use only appropriate tools. If specified by the product documentation, special tools must be used.
- ⇒ Use lifting devices and tools correctly and safely.
- ⇒ Wear appropriate protective clothing, e.g. safety glasses, safety shoes and safety gloves.
- ⇒ Never stay under suspended loads.
- ⇒ Clean up liquids from the floor immediately to prevent personnel from slipping.

3.11 Battery safety

Batteries contain reactive chemicals in a solid housing. Inappropriate handling may result in injuries or equipment damage.



CAUTION

Risk of injury through incorrect handling!

- ⇒ Do not attempt to reactivate discharged batteries by heating or other methods (danger of explosion and corrosion).
- ⇒ Never charge batteries (danger from leakage and explosion).
- ⇒ Never throw batteries into a fire.
- ⇒ Do not dismantle batteries.
- ⇒ Handle with care. Incorrect extraction or installation of a battery can damage equipment.

Note: Environmental protection and disposal! The batteries contained in the product should be considered as hazardous material for land, air and sea transport in the sense of the legal requirements (danger of explosion). Dispose batteries separately from other refuse. Observe the legal requirements given in the country of installation.

3.12 Protection against pressurized Systems

Certain Motors (ADS, ADM, 1MB etc.) and drives, corresponding to the information in the Project Planning manual, must be provided with and remain under a forced load such as compressed air, hydraulic oil, cooling fluid or coolant. In these cases, improper handling of the supply of the pressurized systems or connections of the fluid or air under pressure can lead to injuries or accidents.



CAUTION

Danger of injury when pressurized systems are handled by untrained personnel!

- ⇒ Do not attempt to disassemble, to open or to cut a pressurized system.
- ⇒ Observe the operation restrictions of the respective manufacturer.
- ⇒ Before the disassembly of pressurized systems, lower pressure and drain off the fluid or gas.
- ⇒ Use suitable protective clothing (for example protective eyewear, safety shoes and gloves)
- ⇒ Remove any fluid that has leaked out onto the floor immediately.

Note: Environmental protection and disposal! The fluids used in the operation of the pressurized system equipment is not environmentally compatible. Fluid that is damaging to the environment must be disposed of separate from normal waste. Observe the national specifications of the country of installation.

4 Module Layout, Address Assignments

4.1 Base Module




Fig. 4-1: BTA15 Basic module

The BTA15 base module permits a maximum of eight standard switching elements of the Telemecanique **ZB2-B...** program to be inserted (any elements). Each element features a maximum of two contacts and one indicator lamp. All knockouts in the front panel are pre-milled to 0.5 mm. The next section explains how such a knockout can be opened. Insert strips provide for key labeling.

Instructions for installing additional switches



ESD – electrostatic sensitive components!

⇒ Whenever you work in the open unit, your working position and the employed tools must comply with the ESD protective measures.

To insert an additional switch element in the front of the BTA15.3 unit, use the following procedure:

1. Unscrew the enclosure from the unit.
2. Dismantle the electronics unit.
 - a) Use a 5.5-mm socket wrench to loosen the six spacing bolts A and B (see Fig. 4-2).

Caution: There are different lengths !

- b) Remove the electronics block with the LK-BIB and the main board.




Fig. 4-2: Location of the spacing bolts

Note: Removing the electronics part is an important step. Removing the knockouts may produce chips that can be the cause of malfunctions.

3. Use a knife (scalpel) to cut the front film in the shape of the pre-milled knockout contour (see Fig. 4-3)




Fig. 4-3: Front panel cross section

4. Using a knife, slightly scratch along the pre-milled front panel contour (0.5 mm thick).
5. Use your thumb to knock out the center part.
6. Remove the resulting burr and clean the chips off the front panel.
7. Insert the required front panel element (pushbutton, lamp, key switch) and screw it tight.
8. Plug the required switching elements (NC/NO contacts) onto the main board, and select the jumper positions for internal or external mode of the right-hand switching element.
9. Position the board block onto the switching elements.
10. Tighten the six spacing bolts.
11. Position the enclosure and tighten the retaining screws.

Main board configuration




Fig. 4-4: Main board




Fig. 4-5: Plug-in socket

The main board is equipped with eight plug-in sockets. Such a socket features two locations for switching contacts (NC/NO contacts) or lamp contacts. The first contact is used for internal bus operation. To support external wiring, jumpers permit the right-hand auxiliary contact of each switch to be set to either bus interface (internal) or X2 and X3 terminal bar (external). Illumination elements are controlled via pins 1 and 4 (as shown in the Figure).

Addressing

Outputs	Position	Address
	Lamp S1	Q*0.0
	Lamp S2	Q*0.1
	Lamp S3	Q*0.2
	Lamp S4	Q*0.3
	Lamp S5	Q*0.4
	Lamp S6	Q*0.5
	Lamp S7	Q*0.6
	Lamp S8	Q*0.7

Fig. 4-6: Lamp addresses within the basic module

Inputs	Circuit Element / Location	Address
	S 1-left aux. contact	I*6.0
	S 1-right aux. contact	I*6.1
	S 2-left aux. contact	I*6.2
	S 2-right aux. contact	I*6.3
	S 3-left aux. contact	I*6.4
	S 3-right aux. contact	I*6.5
	S 4-left aux. contact	I*6.6
	S 4-right aux. contact	I*6.7
	S 5-left aux. contact	I*7.0
	S 5-right aux. contact	I*7.1
	S 6-left aux. contact	I*7.2
	S 6-right aux. contact	I*7.3
	S 7-left aux. contact	I*7.4
	S 7-right aux. contact	I*7.5
	S 8-left aux. contact	I*7.6
	S 8-right aux. contact	I*7.7

Fig. 4-7: Addresses of the circuit elements with the basic module

Interface converter

In the normal state of the BTA15.1, the X8A and X9 connectors provide RS422 communication capability. The interface converter enables the data exchange between a BTC06 manual control unit or an PLC to be organized.




Fig. 4-8: Switching principle of the interface converter

As shown in the Figure, the converter has a switching function. In its normal position, there is a connection between RS422 IN and RS422 OUT. This means that data can be received and transmitted using the RS422 protocol. The converter will be needed to connect a RS232 port with a RS422 device. If an MTS-P module (PLC plug-in module at the BTV20 unit) is connected to a BTA15.1 unit, the converter automatically switches over and the X8 connection (RS232 IN) becomes operational. A prerequisite is the correct initialization of the MTS-P module. Devices connected to X9 may exchange data with the PLC.

Note: Thus, the X8A (RS422 IN) connector is without a function

Using a BTC06 unit requires the key switch on the NB or VA module. The manual control unit is connected with the SPS when the key switch is in its left-hand position.

Note: In this case, the X9 connector is without a function.

Using a BTC06 manual control unit and maintaining communication with other RS422 devices at the same time is not possible.

4.2 Type NA Emergency Stop Module




Fig. 4-9: Type NA emergency stop module

The NA emergency stop module possesses an emergency stop switch and a signal lamp that can be switched on via INTERBUS.

From the emergency stop switch, an NC contact is looped into each emergency stop circuit. Another NC contact is connected to the INTERBUS as an auxiliary contact; likewise is the signal lamp.

Addressing of the NA module

Outputs	Location	Address
	Lamp	Q*1.0

Fig. 4-10 Address of the signal lamp within the E-stop module

Inputs	Circuit Element / Location	Address
	Aux. contact E-stop	I*8.0

Fig. 4-11: Address of the auxiliary contact within the E-stop module

4.3 Type NB Emergency Stop Module




Fig. 4-12: Type NB emergency stop module

In addition to the emergency stop switch, the NB module features a connection for the BTC06 manual control unit, and a key switch that functionally connects the manual control unit (the switch positions are explained in Fig. 4-13).

From the emergency stop button, an NC contact is looped into each of the two emergency stop circuits. Another NC contact is connected to the INTERBUS as an auxiliary contact.

The connection for the manual control unit possesses two emergency stop circuits that are jumpered by the shorting plug during normal operation. When a manual control unit is connected, the emergency stop contacts of the socket are jumpered during the insertion process by setting the adjacent key switch to its right-hand position. This version employs two confirmation circuits; the third one is routed via the key switch.

Switching positions of the key switch




Fig. 4-13: Switching positions of the key switch

Switch for starting the BTC06 manual control unit

For starting a BTC06 manual control unit at the BTA15.1 it is necessary to take the switch on the backside of the unit (see Fig. 4-14) to the correctly position. The switch position **must** always be on module left.




Fig. 4-14: Location of the switch for BTC06 connection

Addressing of the NB module**Inputs**

Circuit Element / Location	Address
Aux. contact E-stop	I*8.0
Aux. contact keyswitch	I*8.4

Fig. 4-15: Address of the auxiliary contact within the E-stop module

4.4 Type VA Feed Module




Fig. 4-16: Type VA feed module

This module features a Gray code override switch, a key switch, and a connection for a BTC06 manual control unit.

The connection for the manual control unit possesses two emergency stop circuits that are jumpered by the shorting plug during normal operation. When a manual control unit is connected, the emergency stop contacts of the socket are jumpered during the insertion process by the adjacent key switch. This version employs two confirmation circuits; the third one is routed via the key switch.

Switching positions of the key switch

Chapter 2.3 Emergency Stop Module type NB

Switch for starting the BTC06 manual control unit

Chapter 2.3 Emergency Stop Module type NB

Addressing of the VA module

Inputs	Circuit Element / Location	Address
	Override bit 0	I*8.0
	Override bit 1	I*8.1
	Override bit 2	I*8.2
	Override bit 3	I*8.3
	Aux. contact keyswitch	I*8.4

Fig. 4-17: Addresses of the feedrate override switch

Gray-code table The feedrate override switch outputs a 4-bit gray-code signal. The code is assigned to the scale value as shown in the table below:

Scale value	Bit 0	Bit 1	Bit 2	Bit 3
0 %				
1 %	X			
2 %	X	X		
4 %		X		
6 %		X	X	
8 %	X	X	X	
10 %	X		X	
20 %			X	
30 %			X	X
40 %	X		X	X
50 %	X	X	X	X
60 %		X	X	X
70 %		X		X
80 %	X	X		X
100 %	X			X
120 %				X

Fig. 4-18: Gray-code table of the VA module

4.5 Type VB Feed Module




Fig. 4-19: Type VB feed module

This feed module for special machines features two Gray code override switches for feed and spindle.

Addressing of the VB module

Inputs	Circuit Element / Location	Address
	Feedrate override bit 0	I*8.0
	Feedrate override bit 1	I*8.1
	Feedrate override bit 2	I*8.2
	Feedrate override bit 3	I*8.3
	Spindle override bit 4	I*8.4
	Spindle override bit 5	I*8.5
	Spindle override bit 6	I*8.6
	Spindle override bit 7	I*8.7

Fig. 4-20: Addresses of the feedrate override switch (left)

Gray-code table The both feedrate override switch output a 4-bit gray-code signal. The code is assigned to the scale value as shown in the table below:

Scale value Feed (Bit 0-3)	Scale value Spindle (Bit 4-7)	Bit 0 / 4	Bit 1 / 5	Bit 2 / 6	Bit 3 / 7
0 %	45 %				
1 %	50 %	X			
2 %	55 %	X	X		
4 %	60 %		X		
6 %	65 %		X	X	
8 %	70 %	X	X	X	
10 %	75 %	X		X	
20 %	80 %			X	
30 %	85 %			X	X
40 %	90 %	X		X	X
50 %	95 %	X	X	X	X
60 %	100 %		X	X	X
70 %	105 %		X		X
80 %	110 %	X	X		X
100 %	115 %	X			X
120 %	120 %				X

Fig. 4-21: Gray-code table of the VB module

5 Bus systems

5.1 Overview




Fig. 5-1: Overview of the bus systems address divisions

5.2 INTERBUS-S

Characteristics of the INTERBUS Module

- INTERBUS-S ID-code 3 (Digital devices with inputs and outputs)
- Remote bus, 500 Kbaud with 2 conductors
- Three words data width of the module, i.e., 48 Bit.
24 outputs, 40 inputs
- 24 Volt level for all inputs,
32 inputs for internal modules and switching devices without physical separation,
further 8 physically separated inputs (input byte 4) on a 9 pin terminal (X5) of the INTERBUS module.
- All 24 outputs at 24 Volt level,
16 outputs for internal indicator lights and modules
further 8 outputs as physically separated external outputs on a 10 pin terminal (X4) of the INTERBUS module.

Status Displays




Fig. 5-2: Location of the status displays

LED	Meaning
RD, red	Remote bus disable is ON, if the remote bus is switched off.
BA, green	Bus active ON, if an INTERBUS-S transmission takes place.
RC, green	Remote bus check - monitoring of the incoming INTERBUS cable (X6). RC ON if the link is O.K. RC OFF in case of INTERBUS-S reset by the control
U, green	Supply voltage applied

Fig. 5-3: INTERBUS-S status LEDs

5.3 BT Bus

The BT bus can be used to connect up to four operator terminals of type BTM15/16 or BTA15. The total maximum length of the BT bus may be up to **50 m**. This applies both to the connection of only one device and to the connection of the permissible maximum number of 4 devices. It is **not** possible to quickly access the I/O data of the operator terminals from the SPC (e.g. %IBP*.*)).

The address assignments required for programming can be found in the respective documents of the devices to be connected.

Addressing

The BT bus is addressed by assigning a logic user number in the I/O editor of the SPC programming interface. Each input core image storage as well as each output core image storage is assigned its own logic address.

Each of the two core image storages has a size of 128 bytes, which are available for the operating devices connected. The number of bytes assigned in the core image storage depends on the operating device (see Fig. 5-4).

Type of device	Storage assignment in the input/output core image
BTM15	Depending on the configuration 2 bytes for digital I/Os (always assigned) 2 additional bytes for each module (except handwheel) 4 additional bytes for handwheel module
BTM16	14 bytes
BTA15	6 bytes

Fig. 5-4: Storage requirements of operating devices

Depending on the physical order of the operating devices connected to the BT bus, the addresses of the devices are assigned in the input and output core image storage without any gaps, according to the storage requirements of the operating devices. The example (Fig. 5-5) illustrates the principle of the storage assignment of the BT bus.




Fig. 5-5: Storage assignment of BT bus

6 Technical Data

6.1 General Technical Data

Weight	Approx. 2,2 kg
Protection	Front plate, basic module IP65 Housing IP20 DIN40 050, IEC 529
Maximum ambient temperature	Operation +5°C to +45°C Transportation -20°C to +60°C
Air pressure (Operation)	860 to 1060 hPa, 1500 m
Max. heat dissipation	Approx. 10 W
Front plate surface	Varnished aluminum and holohedrally let in polyester foil resistant against chemicals
Color	RAL 7035 light gray
24V inputs	U_{IN} = typ. 18-30V potential free I_{IN} = min. 7mA
24V outputs	U_{OUT} = typ. 18-30V potential free I_{OUT} = typ. 200mA
Max. internal current absorption	I_{Max} = approx. 1mA (with 8 lamps equipped)
Acknowledge circuits	Rated voltage: 24V DC / 42 V AC Rated current: 2A DC / 3A AC
Emergency Stop	Rated voltage: 24V DC / 42 V AC Rated current: 2A DC / 3A AC

6.2 Interface Converter

Baudrate	0 to 38400 Baud
Input voltage RS232	± 5 to ± 12 V
Output voltage RS422/485	0/5 V, 5V diff., max. 60mA
+5V Output for bus connection	max. 50mA

7 Connections

7.1 Location of the Terminal Connectors




Fig. 7-1: Location of the terminal connectors

7.2 24V Outputs X4 (potential free)

Addressing	Terminal	Address
	X4 - 1	O *.2.0
	X4 - 2	O *.2.1
	X4 - 3	O *.2.2
	X4 - 4	O *.2.3
	X4 - 5	O *.2.4
	X4 - 6	O *.2.5
	X4 - 7	O *.2.6
	X4 - 8	O *.2.7

Fig. 7-2: Addressing of the 24V outputs (X4)

7.3 24V Inputs X5 (potential free)

Addressing	Terminal	Address
	X5 - 1	I *.10.0
	X5 - 2	I *.10.1
	X5 - 3	I *.10.2
	X5 - 4	I *.10.3
	X5 - 5	I *.10.4
	X5 - 6	I *.10.5
	X5 - 7	I *.10.6
	X5 - 8	I *.10.7

Fig. 7-3: Addressing of the 24V inputs (X5)

7.4 INTERBUS-S Interface IN (X6)

Pin	Signal	Pin	Signal
1	DO1 Data Out 1	2	DI1 Data in 1
3	GND	4	N. C.
5	N. C.	6	/DO1 Data Out 1
7	/DI1 Data in 1	8	N. C.
9	N. C.		

Fig. 7-4: INTERBUS IN (X6)

7.5 INTERBUS-S Interface OUT (X7)

Pin	Signal	Pin	Signal
1	DO2 Data Out 2	2	DI2 Data in 2
3	GND	4	N. C.
5	+ 5 V out	6	/DO2 Data Out 2
7	/DI2 Data in 2	8	N. C.
9	RBST		

Fig. 7-5: INTERBUS OUT (X7)

7.6 Interface RS232 IN (X8)

Pin	Signal	Pin	Signal
1	Shield	2	/TxD
3	/RxD	4	DTR
5	GND	6	
7	RTS	8	
9			

Fig. 7-6: RS232 pin assignment X8

The interface converter's RS232 input is directly wired (socket and plug) to the MTS-P's modem interface.

7.7 Interface RS422 IN (X8A)

Pin	Signal	Pin	Signal
1	Shield	2	N. C.
3	N. C.	4	RS422 RxD+
5	RS422 RxD-	6	N. C.
7	Signal Ground	8	N. C.
9	RS422 TxD+	10	Ground
11	RS422 TxD-	12	+5 V out
13	N. C.	14	N. C.
15	N. C.		

Fig. 7-7: RS422 pin assignment X8A

7.8 Interface RS422 OUT (X9)

Pin	Signal	Pin	Signal
1	Shield	2	N. C.
3	N. C.	4	RS422 RxD+
5	RS422 RxD-	6	N. C.
7	Signal Ground	8	N. C.
9	RS422 TxD+	10	Ground
11	RS422 TxD-	12	+5 V out
13	N. C.	14	N. C.
15	N. C.		

Fig. 7-8: RS422 pin assignment X9

7.9 Terminal Connectors X1...X3




Fig. 7-9: Terminal connectors X1...3

7.10 Terminal Connectors X4 and X5




Fig. 7-10: Terminal Connectors X4 and X5

7.11 E-Stop and Acknowledge Circuits





Fig. 7-11: Application example E-Stop and acknowledge circuits



Not_app_VA.FH7

Fig. 7-12: Application example E-Stop and acknowledge circuits at connection of a BTC06

In this example, the BTA15 is shown together with a BTC06. For a better overview only one circuit is displayed. Two acknowledge circuits are used for modules NB and VA together with the BTC06. The third circuit can be used alternative by the customer.

8 Dimensions

8.1 Enclosure Dimensions




Fig. 8-1: Enclosure dimensions

8.2 Mounting Dimensions





Fig. 8-2: Mounting dimensions

9 Typical Applications

9.1 INTERBUS-S-Connection



App_ib.FH7

Fig. 9-1: INTERBUS-S connection example

9.2 BT Bus Connection




Fig. 9-2: BT Bus connection example

9.3 RS422 wiring with BTV06, MTS-R and BTC06

Unit Arrangement




Fig. 9-3: Application example for RS422 connection with BTV06 and MTS-R




Fig. 9-4: Wiring of the RS422-Application

Standard Interface connectors

There are appropriate connectors available for both RS422 and RS485 communication. These include termination in the housing already. The cable can be mounted with the use of screw-in clamps. Pin assignment of both connectors is illustrated (see Fig. 9-5).

Which connector housing is to be used with which interface cable is specified in chapter 10.2 (accessories) per the table.




Fig. 9-5: Connector assignment of the standard connector housing

Termination can be added by using the appropriate switch.

10 Ordering Information

10.1 Type code

Abbrev. Column	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	
Example:	B	T	A	1	5	.	1	-	N	A	-	W	K	-	B	S																									

1. Product group
 - 1.1 BTA = BTA
2. Line
 - 2.1 15 = 15
3. Design
 - 3.1 1 = 1
4. Configuration ^①


fixed and documented by Rexroth Indramat.

 - 4.1 e.g., NA-WK = NA-WK
(Columns: 9...10 = Module slot 1
12...13 = Module slot 2)
5. Communications bus
 - 5.1 INTERBUS-S / BT-BUS. = BS
 - 5.2 without communications bus = NN

Note:

① Type and design of module slot 1 --> see INN 48.11, attachment 1, "Modules for machine control board"

Illustration example: BTA15.1















Configuration	Component slot							
Type code	1	2	3	4	5	6	7	8
Columns 12...13	1	2	3	4	5	6	7	8
WK	A2	A2	NN	NN	F7	K6	NN	NN

Type.FH7

Fig. 10-1: Type code BTA15.1

10.2 Accessories

Connectors and Standard Cables

Order designation of standard cables	Matching connector of unit	INDRAMAT cable	Cable end type
IKB0193/000,0 MN: 282 041 (RS232, max 2m)	INS0525/L01  9 pin/male	INK0234	INS0526/L01  9 pin/female
IKS0056/000,0 MN: 255 968 (Interbus cable)	INS0525/L01  9pin./male	INK0234	INS0526/L01  9pin./female
IKS0190/000,0 Standard interface cable Connection BTC06	INS0624/C 		INS0631/C 
IKB0015/000,0 MN: 282 870 (RS422, max 400m)	INS0645/K01  15 pin/male	INK0234	INS0645/K01  15 pin/male
IKB0016/000,0 MN: 282 871 (RS422, max 400m)	INS0645/K01  15 pin/male	INK0234	INS0526/L01  9 pin/female
INS0525/L01 MN: 259 759	 INS0525/L01 (9 pin/male)	D-subminiature plug-in connector	
INS0526/L01 MN: 259 762	 INS0526/L01 (9 pin/male)	D-subminiature plug-in connector	



INS0619/K01 MN: 279 583	 <p>Y-connector for customer connection with termination</p> <p>INS0619/K01 RS485 (15 pin/male)</p>
INS0645/K01 MN: 282 040	 <p>Connector for customization with termination.</p> <p>INS0645/K01 RS422 (15 pin/male)</p>

Fig. 10-2: Connector and cable accessories of the BTA15

11 List of Figures

- Fig. 1-1: BTA15 Front view 1-1
- Fig. 3-1: Classes of danger with ANSI 3-1
- Fig. 4-1: BTA15 Basic module 4-1
- Fig. 4-2: Location of the spacing bolts 4-2
- Fig. 4-3: Front panel cross section 4-2
- Fig. 4-4: Main board 4-3
- Fig. 4-5: Plug-in socket 4-3
- Fig. 4-6: Lamp addresses within the basic module 4-4
- Fig. 4-7: Addresses of the circuit elements with the basic module 4-4
- Fig. 4-8: Switching principle of the interface converter 4-5
- Fig. 4-9: Type NA emergency stop module 4-6
- Fig. 4-10 Address of the signal lamp within the E-stop module 4-6
- Fig. 4-11: Address of the auxiliary contact within the E-stop module 4-6
- Fig. 4-12: Type NB emergency stop module 4-7
- Fig. 4-13: Switching positions of the key switch 4-7
- Fig. 4-14: Location of the switch for BTC06 connection 4-8
- Fig. 4-15: Address of the auxiliary contact within the E-stop module 4-8
- Fig. 4-16: Type VA feed module 4-9
- Fig. 4-17: Addresses of the feedrate override switch 4-10
- Fig. 4-18: Gray-code table of the VA module 4-10
- Fig. 4-19: Type VB feed module 4-11
- Fig. 4-20: Addresses of the feedrate override switch (left) 4-11
- Fig. 4-21: Gray-code table of the VB module 4-12
- Fig. 5-1: Overview of the bus systems address divisions 5-1
- Fig. 5-2: Location of the status displays 5-2
- Fig. 5-3: INTERBUS-S status LEDs 5-2
- Fig. 5-4: Storage requirements of operating devices 5-3
- Fig. 5-5: Storage assignment of BT bus 5-4
- Fig. 7-1: Location of the terminal connectors 7-1
- Fig. 7-2: Addressing of the 24V outputs (X4) 7-1
- Fig. 7-3: Addressing of the 24V inputs (X5) 7-1
- Fig. 7-4: INTERBUS IN (X6) 7-2
- Fig. 7-5: INTERBUS OUT (X7) 7-2
- Fig. 7-6: RS232 pin assignment X8 7-2
- Fig. 7-7: RS422 pin assignment X8A 7-3
- Fig. 7-8: RS422 pin assignment X9 7-3
- Fig. 7-9: Terminal connectors X1...3 7-4
- Fig. 7-10: Terminal Connectors X4 and X5 7-5
- Fig. 7-11: Application example E-Stop and acknowledge circuits 7-6
- Fig. 7-12: Application example E-Stop and acknowledge circuits at connection of a BTC06 7-7
- Fig. 8-1: Enclosure dimensions 8-1

- Fig. 8-2: Mounting dimensions 8-2
- Fig. 9-1: INTERBUS-S connection example 9-1
- Fig. 9-2: BT Bus connection example 9-2
- Fig. 9-3: Application example for RS422 connection with BTV06 and MTS-R 9-3
- Fig. 9-4: Wiring of the RS422-Application 9-4
- Fig. 9-5: Connector assignment of the standard connector housing 9-5
- Fig. 10-1: Type code BTA15.1 10-1
- Fig. 10-2: Connector and cable accessories of the BTA15 10-3

12 Index

2

24V 6-1
24V Inputs X5 7-1
24V Outputs X4 7-1

A

Acknowledge circuit 7-6
Additional switch element 4-1
Address of the auxiliary contact 4-6
Addresses of the circuit elements 4-4
Addresses of the feedrate override switch 4-10, 4-11
Addressing 4-4
Air pressure 6-1
Appropriate use
 Area of application 2-2
 Introduction 2-1
 Uses 2-2

B

Base module 4-1
Baudrate 6-1
BTC06 7-7
BTC06-connection 4-8
Bus active ON 5-2

C

Cable accessories 10-3
Characteristics of the INTERBUS module 5-2
Color 6-1
Connections 7-1
Connector housing 9-5
Converter 4-5

D

Data width 5-2

E

ESD 4-1
E-Stop 7-6
E-stop module signal lamp address 4-6
E-stop module type NA 4-6
E-stop module type NB 4-8

F

Feedrate override module type VA 4-10
Front view 1-1

G

Gray-code table 4-10, 4-12

I

Illumination elements 4-3
Inappropriate use 2-2
 Consequences, Discharge of liability 2-1
Input voltage 6-1

Inputs 4-4
INTERBUS IN 7-2
INTERBUS OUT 7-2
INTERBUS-S 5-2
INTERBUS-S status LEDs 5-2
Interface converter 4-5, 6-1

K

Key switch 4-7, 4-9

L

Lamp addresses 4-4
Lamp contact 4-3

M

Main board 4-3
Manual control unit 4-7, 4-9
Max. ambient temperature 6-1
Max. heat dissipation 6-1
Module layout 4-1
Mounting dimensions 8-2

O

Output for bus connection 6-1
Output voltage 6-1
Outputs 4-4

P

Physical separation 5-2
Plug-in socket 4-3
Protection 6-1

R

Remote bus 5-2
Remote bus check 5-2
RS232 pin assignment X8 7-2
RS422 pin assignment X8A 7-3
RS422 pin assignment X9 7-3

S

Safety Instructions for Electric Servo Drives and Controls 3-1
Shorting plug 4-9
Status displays 5-2
Surface 6-1
Switching positions of the key switch 4-7

T

Technical data 6-1
Telemecanique 1-1
Terminal connectors 7-1
Terminal connectors X1...3 7-4
Terminal Connectors X4 and X5 7-5
Type NA emergency stop module 4-6
Type NB emergency stop module 4-7
Type VA feed module 4-9
Type VB feed module 4-11

U

Use *See appropriate use and inappropriate use*

W

Weight 6-1

X

X1...3 7-4
X4 7-1
X4 and X5 7-5
X5 7-1
X6 7-2
X7 7-2
X8 7-2
X8A 7-3
X9 7-3

Z

ZB2 serie 1-1

13 Kundenbetreuungsstellen - Sales & Service Facilities

Deutschland – Germany

vom Ausland:

(x) nach Landeskennziffer weglassen!!

from abroad:

don't dial (x) after country code!

Vertriebsgebiet Mitte <input checked="" type="checkbox"/> SALES Germany Centre <input checked="" type="checkbox"/> Service Rexroth Indramat GmbH Bgm.-Dr.-Nebel-Str. 2 97816 Lohr am Main Telefon: +49 (0)9352/40-0 Telefax: +49 (0)9352/40-4885 Kompetenz- Zentrum Europa	SERVICE CALL ENTRY CENTER MO – FR von / from 7 – 18 Tel. +49 (0) 9352 40 50 60 <u>service@indramat.de</u>	SERVICE HOTLINE MO – FR von / from 17 - 07 + SA / SO Tel.: +49 (0)172 660 04 06 oder / or Tel.: +49 (0)171 333 88 26	SERVICE ERSATZTEILE / SPARES verlängerte Ansprechzeit: - extended office time - ♦ nur an Werktagen - only on working days - ♦ von 15 -18 Uhr - from 15-18 o'clock - Tel. +49 (0) 93 52/40 42 22
Vertriebsgebiet Süd <input checked="" type="checkbox"/> SALES Germany South <input checked="" type="checkbox"/> Service Rexroth Indramat GmbH Ridlerstraße 75 80339 München Telefon: +49 (0)89/540138-30 Telefax: +49 (0)89/540138-10 indramat.mue@t-online.de	Gebiet Südwest <input checked="" type="checkbox"/> SALES Germany South-West <input checked="" type="checkbox"/> Service Mannesmann Rexroth AG Vertrieb Deutschland – VD-BI Geschäftsbereich Rexroth Indramat Regionalzentrum Südwest Ringstrasse 70 / Postfach 1144 70736 Fellbach / 70701 Fellbach Tel.: +49 (0)711/57 61–100 Fax: +49 (0)711/57 61–125	Vertriebsgebiet Ost <input checked="" type="checkbox"/> SALES Germany East <input checked="" type="checkbox"/> Service Rexroth Indramat GmbH Beckerstraße 31 09120 Chemnitz Telefon: +49 (0)371/35 55-0 Telefax: +49 (0)371/35 55-333	Vertriebsgebiet Nord <input checked="" type="checkbox"/> SALES Germany North <input checked="" type="checkbox"/> Service Mannesmann Rexroth AG Vertriebsniederlassung Region Nord Gesch.ber. Rexroth Indramat Walsroder Str. 93 30853 Langenhagen Telefon: +49 (0) 511/72 66 57-0 Telefax: +49 (0) 511/72 66 57-93
Vertriebsgebiet West <input checked="" type="checkbox"/> SALES Germany West <input checked="" type="checkbox"/> Service Mannesmann Rexroth AG Vertrieb Deutschland Regionalzentrum West Borsigstrasse 15 D - 40880 Ratingen Telefon: +49 (0)2102/409-0 Telefax: +49 (0)2102/409-406	Vertriebsgebiet Mitte <input checked="" type="checkbox"/> SALES Germany Centre <input type="checkbox"/> Service Mannesmann Rexroth AG Gesch.ber. Rexroth Indramat Lilistraße 14-18 63067 Offenbach Telefon: +49 (0) 69/82 00 90-0 Telefax: +49 (0) 69/82 00 90-80	Vertriebsgebiet Ost <input checked="" type="checkbox"/> SALES Germany East <input type="checkbox"/> Service Mannesmann Rexroth AG GB Rexroth Indramat GmbH Holzhäuser Str. 122 04299 Leipzig Telefon: +49 (0)341/86 77-0 Telefax: +49 (0)341/86 77-219	Vertriebsgebiet Nord <input checked="" type="checkbox"/> SALES Germany North <input type="checkbox"/> Service Rexroth Indramat GmbH Kieler Straße 212 22525 Hamburg Telefon: +49 (0)40/85 31 57-0 Telefax: +49 (0)40/85 31 57-15

Kundendienstniederlassungen in Deutschland - Service agencies in Germany

Europa – Europe

vom Ausland: (x) nach Landeskennziffer weglassen,

0 nach Landeskennziffer mitwählen (Italien)!

from abroad: don't dial (x) after country code,

dial 0 after country code (Italy)!

Austria <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth Ges.m.b.H. Gesch.ber. Rexroth Indramat Hägelingasse 3 A - 1140 Wien Telefon: +43 (0)1/9852540-400 Telefax: +43 (0)1/9852540-93	Austria <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth G.m.b.H. Gesch.ber. Rexroth Indramat Industriepark 18 A - 4061 Pasching Telefon: +43 (0)7221/605-0 Telefax: +43 (0)7221/605-21	Belgium <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth N.V.-S.A. Gesch.ber. Rexroth Indramat Industrielaan 8 B-1740 Ternat Telefon: +32 (0)2/5830719 Telefax: +32 (0)2/5830731 E-mail: indramat@rexroth.be	Denmark <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service BEC AS Zinkvej 6 DK-8900 Randers Telefon: +45 (0)87/11 90 60 Telefax: +45 (0)87/11 90 61
Czech Rep. <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann-Rexroth, spol.s.r.o. Hviezdoslavova 5 CS - 627 00 Brno Telefon: +420 (0)5/48 126 358 Telefax: +420 (0)5/48 126 112	England <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth Ltd. Rexroth Indramat Division Broadway Lane, South Cerney GB - Cirencester, Glos GL7 5UH Telefon: +44 (0)1285/863000 Telefax: +44 (0)1285/863030	Finland <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Rexroth Mecman Oy Rexroth Indramat division Ansatie 6 SF-017 40 Vantaa Telefon: +358 (0)9/84 91-11 Telefax: +358 (0)9/84 91-13 60	France <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth S.A. Division Rexroth Indramat Parc des Barbanniers 4, Place du Village F-92632 Gennevilliers Cedex Telefon: +33 (0)141 47 54 30 Telefax: +33 (0)147 94 69 41 Hotline: +33 (0)6 08 33 43 28
France <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth S.A. Division Rexroth Indramat 270, Avenue de Lardenne F - 31100 Toulouse Telefon: +33 (0)5 61 49 95 19 Telefax: +33 (0)5 61 31 00 41	France <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth S.A. Division Rexroth Indramat 91, Bd. Irène Joliot-Curie F - 69634 Vénissieux – Cedex Telefon: +33 (0)4 78 78 53 65 Telefax: +33 (0)4 78 78 53 62	Hungary <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth Kft. Angol utca 34 H - 1149 Budapest Telefon: +36 (1) 364 00 02 Telefax: +36 (1) 383 19 80	Italy <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth S.p.A. Divisione Rexroth Indramat Via G. Di Vittoria, 1 I - 20063 Cernusco S/N.MI Telefon: +39 02/92 36 52 70 Telefax: +39 02/92 36 55 12
Italy <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth S.p.A. Divisione Rexroth Indramat Via Borgomanero, 11 I - 10145 Torino Telefon: +39 011/7 50 38 11 Telefax: +39 011/7 71 01 90	Italy <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth S.p.A. Divisione Rexroth Indramat Via del Progresso, 16 (Zona Ind.) I - 35020 Padova Telefon: +39 049/8 70 13 70 Telefax: +39 049/8 70 13 77	Italy <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth S.p.A. Divisione Rexroth Indramat Via Mascia, 1 I - 80053 Castellammare di Stabia NA Telefon: +39 081/8 71 57 00 Telefax: +39 081/8 71 68 85	Italy <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth S.p.A. Divisione Rexroth Indramat Viale Orian, 38/A I - 40137 Bologna Telefon: +39 051/34 14 14 Telefax: +39 051/34 14 22
Netherlands <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Hydraudyne Hydrauliek B.V. Kruisbroeksestraat 1 (P.O. Box 32) NL - 5281 RV Boxtel Telefon: +31 (0)411/65 19 51 Telefax: +31 (0)411/65 14 83 e-mail: indramat@hydraudyne.nl	Netherlands <input type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Hydrocare B.V. Kruisbroeksestraat 1 (P.O. Box 32) NL - 5281 RV Boxtel Telefon: +31 (0)411/65 19 51 Telefax: +31 (0)411/67 78 14	Norway <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Rexroth Mecman AS Rexroth Indramat Division Berghagan 1 or: Box 3007 N -1405 Ski-Langhus N -1402 Ski Telefon: +47 (0)64 86 41 00 Telefax: +47 (0)64 86 90 62	Poland <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth Sp.zo.o. Biuro Poznan ul. Dabrowskiego 81/85 PL - 60-529 Poznan Telefon: +48 061/847 67 99 Telefax: +48 061/847 64 02
Rumania <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth Sp.zo.o. Str. Drobety nr. 4-10, app. 14 RO - 70258 Bucuresti, Sector 2 Telefon: +40 (0)1/210 48 25 +40 (0)1/210 29 50 Telefax: +40 (0)1/210 29 52	Russia <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Tschudnenko E.B. Arsenia 22 RUS - 153000 Ivanovo Rußland Telefon: +7 093/223 96 33 oder/or +7 093/223 95 48 Telefax: +7 093/223 46 01	Spain <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth S.A. División Rexroth Indramat Centro Industrial Santiga Obradors s/n E-08130 Santa Perpetua de Mogoda Barcelona Telefon: +34 937 47 94 00 Telefax: +34 937 47 94 01	Spain <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Goimendi S.A. División Rexroth Indramat Jolastokieta (Herrera) Apartado 11 37 E - 20017 San Sebastian Telefon: +34 9 43/40 01 63 Telefax: +34 9 43/39 17 99
Sweden <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Rexroth Mecman Svenska AB Rexroth Indramat Division Varuvägen 7 S - 125 81 Stockholm Telefon: +46 (0)8/727 92 00 Telefax: +46 (0)8/647 32 77	Slowenia <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Rexroth Indramat elektromotorji d.o.o. Otoki 21 SLO - 64 228 Zelezniki Telefon: +386 64/61 73 32 Telefax: +386 64/64 71 50	Switzerland-East- <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth Schweiz AG Gesch.ber. Rexroth Indramat Gewerbstraße 3 CH - 8500 Frauenfeld Telefon: +41 (0)52/720 21 00 Telefax: +41 (0)52/720 21 11	Switzerland-West- <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth Suisse SA Département Rexroth Indramat Rue du village 1 CH - 1020 Renens Telefon: +41 (0)21/632 84 20 Telefax: +41 (0)21/632 84 21
Turkey <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth Hidropar A.S. Fevzi Cakmak Cad No. 3 TR - 34630 Sefaköy Istanbul Telefon: +90 212/541 60 70 Telefax: +90 212/599 34 07			

Europäische Kundendienstniederlassungen (ohne Deutschland) - European Service agencies (without Germany)

Africa, Asia, Australia – incl. Pacific Rim

vom Ausland:
from abroad:

(x) nach Landeskennziffer weglassen!
don't dial (x) after country code!

Australia <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service AIMS - Australian Industrial Machinery Services Pty. Ltd. Unit 3/45 Horne ST Campbellfield, VIC 3061 AUS - Melbourne Telefon: +61 (0)3/93 59 02 28 Telefax: +61 (0)3/93 59 02 86	Australia <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth Pty. Ltd. No. 7, Endeavour Way Braeside Victoria, 31 95 AUS – Melbourne Telefon: +61 (0)3/95 80 39 33 Telefax: +61 (0)3/95 80 17 33 Email: mel@rexroth.com.au	China <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Rexroth International Trade (Shanghai) Co., Ltd. Wai Gaoqiao Free Trade Zone No.122, Fu Te Dong Yi Road Shanghai 200131 - P.R.China Telefon: +86 21/58 66 30 30 Telefax: +86 21/58 66 55 23	China <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth (China) Ltd. 15/F China World Trade Center 1, Jianguomenwai Avenue Beijing 100004, P.R.China Telefon: +86 10/65 05 03 80 Telefax: +86 10/65 05 03 79
China <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth (China) Ltd. A-5F., 123 Lian Shan Street Sha He Kou District Dalian 116 023, P.R.China Telefon: +86 411/46 78 930 Telefax: +86 411/46 78 932	China <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth (China) Ltd. Guangzhou Repres. Office Room 1014-1016, Metro Plaza, Tian He District, 183 Tian He Bei Rd Guangzhou 510075, P.R.China Telefon: +86 20/8755-0030 +86 20/8755-0011 Telefax: +86 20/8755-2387	Hongkong <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Rexroth (China) Ltd. 1/F., 19 Cheung Shun Street Cheung Sha Wan, Kowloon, Hongkong Telefon: +852 22 62 51 00 Telefax: +852 27 41 33 44	
India <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth (India) Ltd. Rexroth Indramat Division Plot. 96, Phase III Peenya Industrial Area IND - Bangalore - 560058 Telefon: +91 (0)80/8 39 73 74 Telefax: +91 (0)80/8 39 43 45	India <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth (India) Ltd. Rexroth Indramat Division Plot. A-58, TTC Industrial Area Thane Turbhe Midc Road Mahape Village IND - Navi Mumbai - 400 701 Telefon: +91 (0)22/7 61 46 22 Telefax: +91 (0)22/7 68 15 31	Indonesia <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service PT. Rexroth Wijayakusuma Jl. Raya Bekasi Km 21 Pulogadung RI - Jakarta Timur 13920 Telefon: +62 21/4 61 04 87 +62 21/4 61 04 88 Telefax: +62 21/4 60 01 52	Japan <input type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Rexroth Automation Co., Ltd. Service Center Japan Yutakagaoka 1810, Meito-ku, NAGOYA 465-0035, Japan Telefon: +81 (0)52/777 88 41 +81 (0)52/777 88 53 +81 (0)52/777 88 79 Telefax: +81 (0)52/777 89 01
Japan <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Rexroth Automation Co., Ltd. Rexroth Indramat Division 1F, I.R. Building Nakamachidai 4-26-44, Tsuzuki-ku YOKOHAMA 224-0041, Japan Telefon: +81 (0)45/942 72 10 Telefax: +81 (0)45/942 03 41	Korea <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth-Korea Ltd. Rexroth Indramat Division 1500-12 Dadae-Dong- Saha-Ku Pusan, 604-050 Republic of South Korea Telefon: +82 (0)51/2600 741 Telefax: +82 (0)51/2600 747	South Africa <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service TECTRA Automation (Pty) Ltd. 28 Banfield Road, Industria North RSA - Maraisburg 1700 Telefon: +27 (0)11/673 20 80 Telefax: +27 (0)11/673 72 69	Taiwan <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Rexroth Uchida Co., Ltd. No.1, Tsu Chiang Street Tu Cheng Ind. Estate Taipei Hsien, Taiwan, R.O.C. Telefon: +886 2/2 68 13 47 Telefax: +886 2/2 68 53 88

Kundendienstniederlassungen in Afrika, Asien, Australien, Pazifik - Service agencies in Africa, Asia, Australia, Pacific Rim

Nordamerika – North America

USA <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth Corporation Rexroth Indramat Division 5150 Prairie Stone Parkway USA - Hoffman Estates, IL 60192-3707 Telefon: +1 847/6 45 36 00 Telefax: +1 847/6 45 62 01 service@indramat.com Competence Centre America	USA <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth Corporation Rexroth Indramat Division Central Region Technical Center USA - Auburn Hills, MI 48326 Telefon: +1 248/3 93 33 30 Telefax: +1 248/3 93 29 06	USA <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth Corporation Rexroth Indramat Division Southeastern Technical Center 3625 Swiftwater Park Drive USA - Suwanee Georgia 30174 Telefon: +1 770/9 32 32 00 +1 770/9 32 19 03	USA <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth Corporation Rexroth Indramat Division Northeastern Technical Center 99 Rainbow Road USA - East Granby, Connecticut 06026 Telefon: +1 860/8 44 83 77 +1 860/8 44 85 95
USA <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth Corporation Rexroth Indramat Division Charlotte Regional Sales Office 14001 South Lakes Drive USA - Charlotte, North Carolina 28273 Telefon: +1 704/5 83 97 62 +1 704/5 83 14 86	USA Service HOTLINE +1-800-860-1055 - 7 days / 24hrs -		Canada <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Basic Technologies Corporation Burlington Division 3426 Mainway Drive Burlington, Ontario Canada L7M 1A8 Telefon: +1 905/335 55 11 Telefax: +1 905/335-41 84

Südamerika – South America

Argentina <input checked="" type="checkbox"/> SALES <input type="checkbox"/> Service Mannesmann Rexroth S.A.I.C. Division Rexroth Indramat Acassuso 48 41/7 RA - 1605 Munro (Buenos Aires) Telefon: +54 (0)11/4756 01 40 Telefax: +54 (0)11/4762 6862 e-mail:mannesmann@impsat1.com.ar	Argentina <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service NAKASE Servicio Tecnico CNC Calle 49, No. 5764/66 RA - 1653 Villa Balester Prov. - Buenos Aires Telefon: +54 (0) 11/4768 36 43 Telefax: +54 (0) 11/4768 24 13 e-mail: nakase@usa.net nakase@infovia.com.ar	Brazil <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth Automação Ltda. Divisão Rexroth Indramat Rua Georg Rexroth, 609 Vila Padre Anchieta BR - 09951-270 Diadema-SP [Caixa Postal 377] [BR-09901-970 Diadema-SP] Telefon: +55 (0)11/745 90 60 +55 (0)11/745 90 70 Telefax: +55 (0)11/745 90 50 e-mail: awittwer@rexroth.com.br	Brazil <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth Automação Ltda. Divisão Rexroth Indramat R. Dr.Humberto Pinheiro Vieira, 100 Distrito Industrial BR - 89220-390 Joinville - SC [Caixa Postal 1273] Tel./Fax: +55 (0)47/473 58 33 Mobil: +55 (0)47 974 66 45 e-mail: prochnow@zaz.com.br
Mexico <input checked="" type="checkbox"/> SALES <input checked="" type="checkbox"/> Service Mannesmann Rexroth Mexico S.A. de C.V. Calle Neptuno 72 Unidad Ind. Vallejo MEX - 07700 Mexico, D.F. Telefon: +52 5 754 17 11 +52 5 754 36 84 +52 5 754 12 60 Telefax: +52 5 754 50 73 +52 5 752 59 43 e-mail: gsoria@rexroth-mexico.com			

Kundendienstniederlassungen in Nord-/ Südamerika - Service agencies in North- & South- America

288632

Printed in Germany